

ENVISIONING • EMPOWERING • EXCELLING



MxL83433 and MxL83434
RS-485/422 Quad Receiver
EVK User Manual

Revision History

Document No.	Release Date	Change Description
031UMR00	June 14, 2024	Initial release.

Table of Contents

Introduction	1
MxL83433 EVK Setup and Pre-Configuration	1
MxL83434 EVK Setup and Pre-Configuration	2
Ordering Information	2
Evaluation Kit Overview	3
EVK Schematic	4
EVK PCB Layers (NSOIC16 Package)	5
EVK PCB Layers (TSSOP16 Package)	7
EVK Bill of Materials	9
EVK Setup and Configurations	10
Layout Recommendations	14

List of Figures

Figure 1: Top View of the MxL83433 (NSOIC16) EVK.....	1
Figure 2: Top View of the MxL83434 (TSSOP16) EVK.....	2
Figure 3: MxL83433 Quad Receiver.....	3
Figure 4: MxL83434 Quad Receiver.....	3
Figure 5: MxL8343x EVK Schematic.....	4
Figure 6: EVK PCB Layer 1—Top View (NSOIC16)	5
Figure 7: EVK PCB Layer 2—GND Plane (NSOIC16)	5
Figure 8: EVK PCB Layer 3—Power Plane (NSOIC16)	6
Figure 9: EVK PCB Layer 4—Bottom View (NSOIC16)	6
Figure 10: EVK PCB Layer 1—Top View (TSSOP16).....	7
Figure 11: EVK PCB Layer 2—GND Plane (TSSOP16)	7
Figure 12: EVK PCB Layer 3—Power Plane (TSSOP16)	8
Figure 13: EVK PCB Layer 4—Bottom View (TSSOP16)	8

List of Tables

Table 1: EVK Ordering Part Numbers	2
Table 2: EVK Bill of Materials for NSOIC16	9
Table 3: EVK Bill of Materials for TSSOP16.....	9
Table 4: EVK Header Pin Description	10
Table 5: EVK Header Pin Description and Default Settings	10

Introduction

This document is used for the evaluation kits (EVKs) of the MxL83433 and MxL83434 (MxL8343x) devices. These EVKs provide a platform to evaluate the features and performance of the MxL8343x.

MxL83433 EVK Setup and Pre-Configuration

- The MxL83433 EVK is pre-configured for global enable with RE = V_{CC} and REb = GND. All four receiver outputs are enabled simultaneously in this configuration.
- Apply V_{CC} = 5.0V bench power supply to header J1 at pin 2 (J1.2) or pin 3 (J1.3).
- Apply GND connection to J1 at pin 1 (J1.1).
- J14 and J16 are GND probe points on the EVK.
- When the power V_{CC} is applied at header J1, the LED at location D1 is ON.
- Screw terminal block J5, J30, J26, and J18 are inputs to receiver channel 1, channel 2, channel 3, and channel 4, respectively.
- Apply differential signals at J5, J30, J26, and J18. Monitor the receiver outputs at J7, J10, J23, and J20.
- [Figure 5](#) on page 4 shows the schematic of the EVK.




Figure 1: Top View of the MxL83433 (NSOIC16) EVK

MxL83434 EVK Setup and Pre-Configuration

- The MxL83434 EVK is pre-configured for paired enable with $R12 = V_{CC}$ and $R34 = V_{CC}$. All four receiver outputs are enabled simultaneously in this configuration.
- Apply $V_{CC} = 5.0V$ bench power supply to header J1 at pin 2 (J1.2) or pin 3 (J1.3).
- Apply GND connection to J1 at pin 1 (J1.1).
- J14 and J16 are GND probe points on the EVK.
- When the power V_{CC} is applied at header J1, the LED at location D1 is ON.
- Screw terminal block J5, J30, J26, and J18 are inputs to receiver channel 1, channel 2, channel 3, and channel 4, respectively.
- Apply differential signals at J5, J30, J26, and J18. Monitor the receiver outputs at J7, J10, J23, and J20.
- [Figure 5](#) on page 4 shows the schematic of the EVK.




Figure 2: Top View of the MxL83434 (TSSOP16) EVK

For more information about the MxL8343x devices, refer to the *MxL83433 and MxL83434 Data Sheet (275DS)*.

Ordering Information

The following table lists the ordering part numbers for the evaluation kits.

Table 1: EVK Ordering Part Numbers

EVK Part Number	Description
MXL83433E-ADA-EVK-1	MxL83433 evaluation kit NSOIC16
MXL83434E-AGA-EVK-1	MxL83434 evaluation kit TSSOP16

Evaluation Kit Overview

The following figure shows the pin configuration and logic diagram of the MxL83433 device.




Figure 3: MxL83433 Quad Receiver

The following figure shows the pin configuration and logic diagram of the MxL83434 device.




Figure 4: MxL83434 Quad Receiver

EVK Schematic

The following figure shows the EVK schematic design of the MxL8343x devices.




Figure 5: MxL8343x EVK Schematic

EVK PCB Layers (NSOIC16 Package)




Figure 6: EVK PCB Layer 1—Top View (NSOIC16)




Figure 7: EVK PCB Layer 2—GND Plane (NSOIC16)




Figure 8: EVK PCB Layer 3—Power Plane (NSOIC16)




Figure 9: EVK PCB Layer 4—Bottom View (NSOIC16)

EVK PCB Layers (TSSOP16 Package)




Figure 10: EVK PCB Layer 1—Top View (TSSOP16)




Figure 11: EVK PCB Layer 2—GND Plane (TSSOP16)




Figure 12: EVK PCB Layer 3—Power Plane (TSSOP16)




Figure 13: EVK PCB Layer 4—Bottom View (TSSOP16)

EVK Bill of Materials

Table 2: EVK Bill of Materials for NSOIC16

Item	Quantity	Reference	Manufacturer	Part
1	2	C1, C3	Kemet	C0603C104K5RAC7081, 0.1UF 50V, 0603 X7R
2	1	C2	AVX	478-5235-1-ND, TANTALUM, 10 μ F, 16V, 500m Ω , 2312
3	1	D1	Lumex	67-1553-1-ND LED GREEN DEFUSED SMD, 0805
4	1	J1	Würth Electronics	613 004 111 21 CONN. HEADER 1X4, 2.54mm, 4PIN
5	13	J2, J3, J4, J7, J10, J12, J13, J17, J19, J20, J23, J25, J27	Würth Electronics	613 002 111 21 CONN. HEADER 1X2, 2.54mm, 2PIN
6	4	J5, J18, J26, J30	Würth Electronics	691 244 710 004 TERMINAL BLOCK, HORIZONT 4POS
7	6	J6, J8, J9, J21, J22, J24	Würth Electronics	613 003 111 21 CONN. HEADER 1X3, 2.54mm, 3PIN
8	3	J14, J15, J16	Würth Electronics	613 001 111 21 CONN. HEADER, 1X1, 2.54mm, 1PIN
9	1	R1	Xicon	ERJ-3EKF4700V RES SMD, 470 Ω , 1%, 1/10W, 0603
10	4	R2, R3, R4, R5. Termination resistors. Optional, not stuff by default.	Xicon	ERJ-3EKF1200V RES SMD, 120 Ω , 1%, 1/10W, 0603
11	1	U1	MaxLinear	MXL83433E-ADA-R (NSOIC16)


Table 3: EVK Bill of Materials for TSSOP16

Item	Quantity	Reference	Manufacturer	Part
1	2	C1, C3	Kemet	C0603C104K5RAC7081, 0.1UF 50V, 0603 X7R
2	1	C2	AVX	478-5235-1-ND, TANTALUM, 10 μ F, 16V, 500m Ω , 2312
3	1	D1	Lumex	67-1553-1-ND LED GREEN DEFUSED SMD, 0805
4	1	J1	Würth Electronics	613 004 111 21 CONN. HEADER 1X4, 2.54mm, 4PIN
5	13	J2, J3, J4, J7, J10, J12, J13, J17, J19, J20, J23, J25, J27	Würth Electronics	613 002 111 21 CONN. HEADER 1X2, 2.54mm, 2PIN
6	4	J5, J18, J26, J30	Würth Electronics	691 244 710 004 TERMINAL BLOCK, HORIZONT 4POS
7	6	J6, J8, J9, J21, J22, J24	Würth Electronics	613 003 111 21 CONN. HEADER 1X3, 2.54mm, 3PIN
8	3	J14, J15, J16	Würth Electronics	613 001 111 21 CONN. HEADER, 1X1, 2.54mm, 1PIN
9	1	R1	Xicon	ERJ-3EKF4700V RES SMD, 470 Ω , 1%, 1/10W, 0603
10	4	R2, R3, R4, R5. Termination resistors. Optional, not stuff by default.	Xicon	ERJ-3EKF1200V RES SMD, 120 Ω , 1%, 1/10W, 0603
11	1	U1	MaxLinear	MXL83434E-AGA-R (TSSOP16)

EVK Setup and Configurations

The following table lists the header pin descriptions of the MxL8343x.

Table 4: EVK Header Pin Description

J1	J1-Pin 1	J1-Pin 2	J1-Pin 3	J1-Pin 4
	GND	NC	V_{CC}^1	V_{CC}^1

1. V_{CC} = 3.0V to 5.5V.

The following table lists the header pin factory settings and descriptions of the MxL8343x. For a complete view of the MxL83433 EVK, see [Figure 1](#) on page 1. For a complete view of the MxL83434 EVK, see [Figure 2](#) on page 2.

Table 5: EVK Header Pin Description and Default Settings





Header	Factory Setting	Description
MxL83433 (NSOIC16)		
J8 	Jumper 1-2	Enables all receivers, RE = V_{CC} .
J22 	Jumper 2-3	Enables all receivers, REb = GND.
MxL83434 (TSSOP16)		
J8 	Jumper 1-2	Enables the channel 1 and channel 2 receivers when RE12 = V_{CC} . Disables the channel 1 and channel 2 receivers when RE12 = GND.
J22 	Jumper 2-3	Enables the channel 3 and channel 4 receivers when RE34 = V_{CC} . Disables the channel 3 and channel 4 receivers when RE34 = GND.

Table 5: EVK Header Pin Description and Default Settings (Continued)

Header	Factory Setting	Description
MxL83433 (NSOIC16) and MxL83434 (TSSOP16)		
J2 	Jumper 1-2	Enables power LED.
R2, R3, R4, R5	Not stuff	Receiver termination resistor. Optional, not stuff by default.
J3 	Header 2 pins	<ul style="list-style-type: none"> ■ J3.1: B1 inverting input (test point). ■ J3.2: GND.
J4 	Header 2 pins	<ul style="list-style-type: none"> ■ J4.1: A1 non-inverting input (test point). ■ J4.2: GND.
J5 	4-pin terminal block	<ul style="list-style-type: none"> ■ J5.1: GND. ■ J5.2: B1 inverting input. ■ J5.3: A1 non-inverting input. ■ J5.4: GND.
J6 	Header 3 pins	<ul style="list-style-type: none"> ■ J6.1: V_{CC}. ■ J6.2: R1 output. ■ J6.3: GND.
J7 	Header 2 pins	<ul style="list-style-type: none"> ■ J7.1: R1 output (test point). ■ J7.2: GND.
J9 	Header 3 pins	<ul style="list-style-type: none"> ■ J9.1: V_{CC} ■ J9.2: R2 output. ■ J9.3: GND.
J10 	Header 2 pins	<ul style="list-style-type: none"> ■ J10.1: R2 output (test point). ■ J10.2: GND.
J12 	Header 2 pins	<ul style="list-style-type: none"> ■ J12.1: A2 non-inverting input (test point). ■ J12.2: GND.

Table 5: EVK Header Pin Description and Default Settings (Continued)
















Header	Factory Setting	Description
J13 	Header 2 pins	<ul style="list-style-type: none"> ■ J13.1: B2 inverting input (test point). ■ J13.2: GND.
J30 	4-pin terminal block	<ul style="list-style-type: none"> ■ J30.1: GND. ■ J30.2: A2 non-inverting input. ■ J30.3: B2 inverting input. ■ J30.4: GND.
J25 	Header 2 pins	<ul style="list-style-type: none"> ■ J25.1: A3 non-inverting input (test point). ■ J25.2: GND.
J27 	Header 2 pins	<ul style="list-style-type: none"> ■ J27.1: B3 inverting input (test point). ■ J27.2: GND.
J26 	4-pin terminal block	<ul style="list-style-type: none"> ■ J26.1: GND. ■ J26.2: B3 inverting input. ■ J26.3: A3 non-inverting input. ■ J26.4: GND.
J23 	Header 2 pins	<ul style="list-style-type: none"> ■ J23.1: R3 output (test point). ■ J23.2: GND.
J24 	Header 3 pins	<ul style="list-style-type: none"> ■ J24.1: V_{CC}. ■ J24.2: R3 output. ■ J24.3: GND.
J20 	Header 2 pins	<ul style="list-style-type: none"> ■ J20.1: R4 output (test point). ■ J20.2: GND.
J21 	Header 3 pins	<ul style="list-style-type: none"> ■ J21.1: V_{CC}. ■ J21.2: R4 output. ■ J21.3: GND.

Table 5: EVK Header Pin Description and Default Settings (Continued)

Header	Factory Setting	Description
J17 	Header 2 pins	<ul style="list-style-type: none"> ■ J17.1: B4 inverting input (test point). ■ J17.2: GND.
J19 	Header 2 pins	<ul style="list-style-type: none"> ■ J19.1: A4 non-inverting input (test point). ■ J19.2: GND.
J18 	4-pin terminal block	<ul style="list-style-type: none"> ■ J18.1: GND. ■ J18.2: A4 non-inverting input. ■ J18.3: B4 inverting input. ■ J18.4: GND.
J14 	Header 1 pin	J14.1: GND.
J15 	Header 1 pin	J15.1: V_{CC} .
J16 	Header 1 pin	J16.1: GND.

MxL83433

The MxL83433 device offers a global enable configuration.

All four receiver outputs are enabled simultaneously when $RE = V_{CC}$ or $REb = GND$.

When $RE = GND$ and $REb = V_{CC}$, all four receiver outputs are in a high impedance state.

MxL83434

The MxL83434 device offers a paired enable configuration.

The channel 1 and channel 2 receiver outputs are enabled simultaneously when $RE12 = V_{CC}$.

The channel 3 and channel 4 receiver outputs are enabled simultaneously when $RE34 = V_{CC}$.

When $RE12 = GND$, the channel 1 and channel 2 receiver outputs are in high impedance state.

When $RE34 = GND$, the channel 3 and channel 4 receiver outputs are in high impedance state.

Layout Recommendations

The following are recommended layout practices that are already applied in the EVK:

- Application of bypass capacitors of at least 100nF as close as possible to the V_{CC} terminal of the device.
Note: If the supply source is generated from a linear power supply or regulator, MaxLinear recommends that you use additional 10 μ F (C2) and 100nF (C3) ceramic capacitors.
- Use of at least two vias for the V_{CC} and ground connections of the bypass capacitors to minimize effective via inductance.
- When possible, use of a V_{CC} and ground plane to provide low-inductance traces and signal path.

For more information and tips on layout, refer to the *RS-232 and RS-485 PCB Layout Application Note (293AN)*.



MaxLinear, Inc.
5966 La Place Court, Suite 100
Carlsbad, CA 92008
Tel.: +1 (760) 692-0711
Fax: +1 (760) 444-8598
www.maxlinear.com

The content of this document is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by MaxLinear, Inc. MaxLinear, Inc. assumes no responsibility or liability for any errors or inaccuracies that may appear in the informational content contained in this document. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced into, stored in, or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of MaxLinear, Inc.

EXCEPT AS OTHERWISE PROVIDED EXPRESSLY IN WRITING BY MAXLINEAR, AND TO THE MAXIMUM EXTENT PERMITTED BY LAW: (A) THE MAXLINEAR PRODUCTS ARE PROVIDED ON AN "AS IS" BASIS WITHOUT REPRESENTATIONS OR WARRANTIES OF ANY KIND, INCLUDING WITHOUT LIMITATION ANY IMPLIED OR STATUTORY WARRANTIES AND ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR TITLE; AND (B) MAXLINEAR DOES NOT GUARANTEE THAT THE PRODUCTS WILL BE FREE OF ERRORS OR DEFECTS. MAXLINEAR PRODUCTS SHOULD NOT BE USED IN ANY EMERGENCY, SECURITY, MILITARY, LIFE-SAVING, OR OTHER CRITICAL USE CASE WHERE A FAILURE OR MALFUNCTION COULD CAUSE PERSONAL INJURY OR DEATH, OR DAMAGE TO OR LOSS OF PROPERTY. USERS ASSUME ALL RISK FOR USING THE MAXLINEAR PRODUCTS IN SUCH USE CASE. CUSTOMERS AND USERS ARE SOLELY RESPONSIBLE FOR USING THEIR OWN SKILL AND JUDGMENT TO DETERMINE WHETHER MAXLINEAR PRODUCTS ARE SUITABLE FOR THE INTENDED USE CASE.

MaxLinear, Inc. may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from MaxLinear, Inc., the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

MaxLinear, the MaxLinear logo, and any other MaxLinear trademarks (including but not limited to MxL, Full-Spectrum Capture, FSC, AirPHY, Puma, AnyWAN, VectorBoost, MXL WARE, and Panther) are all property of MaxLinear, Inc. or one of MaxLinear's subsidiaries in the U.S.A. and other countries. All rights reserved.

All third-party marks and logos are trademarks™ or registered® trademarks of their respective holders/owners. Use of such marks does not imply any affiliation with, sponsorship or endorsement by the owners/holders of such trademarks. All references by MaxLinear to third party trademarks are intended to constitute nominative fair use under applicable trademark laws.

The URLs provided are for informational purposes only; they do not constitute an endorsement or an approval by MaxLinear of any of the products or services of the corporation or organization or individual. MaxLinear bears no responsibility for the accuracy, legality or content of the external site or for that of subsequent links. Contact the external site for answers to questions regarding its content.