



MxL8321x
High Performance RS-485/422
Transceivers with Extended
IEC ESD and EFT Protection
EVK User Manual

Revision History

Document No.	Release Date	Change Description
028UMR00	May 3, 2024	Initial release.

Table of Contents

Introduction..... 1

Ordering Information..... 1

Evaluation Kit Overview..... 2

EVK Schematic 3

EVK PCB Layers (NSOIC8 Package)..... 4

EVK Bill of Materials..... 6

EVK Setup and Configurations 7

Layout Recommendations..... 9

List of Figures

Figure 1: Top View of the MxL8321x EVK.....1

Figure 2: MxL8321x Half-Duplex Receiver.....2

Figure 3: MxL8321x EVK Schematic.....3

Figure 4: EVK PCB Layer 1—Top View4

Figure 5: EVK PCB Layer 2—GND Plane4

Figure 6: EVK PCB Layer 3—Power Plane.....5

Figure 7: EVK PCB Layer 4—Bottom View5

List of Tables

Table 1: EVK Ordering Part Numbers 1

Table 2: EVK Bill of Materials 6

Table 3: EVK Header Pin Description 7

Table 4: EVK Header Pin Description and Default Settings 7

Introduction

This document is used for the evaluation kits (EVKs) of the MxL83211, MxL83212, and MxL83214 (MxL8321x) devices. These EVKs provide a platform to evaluate the features and performance of the MxL8321x.

For more information about the MxL8321x devices, refer to the *MxL8321x Data Sheet* (274DS).




Figure 1: Top View of the MxL8321x EVK

Ordering Information

The following table lists the ordering part numbers for the evaluation kits.

Table 1: EVK Ordering Part Numbers

EVK Part Number	Description
MXL83211E-ADA-EVK-1	MxL83211 evaluation kit
MXL83212E-ADA-EVK-1	MxL83212 evaluation kit
MXL83214E-ADA-EVK-1	MxL83214 evaluation kit

Evaluation Kit Overview

The following figure shows the pin configuration and logic diagram of the MxL8321x device.




Figure 2: MxL8321x Half-Duplex Receiver

EVK Schematic




Figure 3: MxL8321x EVK Schematic

MaxLinear Confidential

EVK PCB Layers (NSOIC8 Package)




Figure 4: EVK PCB Layer 1—Top View




Figure 5: EVK PCB Layer 2—GND Plane




Figure 6: EVK PCB Layer 3—Power Plane




Figure 7: EVK PCB Layer 4—Bottom View

EVK Bill of Materials


Table 2: EVK Bill of Materials

Item	Qty	Reference Designator	Manufacturer	Manufacturer Part Number
1	2	C1, C3	KEMET	C0603C104K5RAC7081, 0.1UF 50V, 0603 X7R
2	1	C2	AVX	478-5235-1-ND, TANTALUM, 10μF, 16V, 500mOhm, 2312
3	1	D1	Lumex Opto	67-1553-1-ND LED GREEN DEFUSED SMD, 0805
4	1	J1	Würth Eletronics	613 004 111 21 CONN. HEADER 1X4, 2.54mm, 4PIN
5	7	J2, J4, J8, J9, J14, J15, J18	Würth Eletronics	620 002 111 21 CONN.HEADER, 1X2, 2mm, 2PIN
6	4	J3, J7, J13, J17	Würth Eletronics	613 003 111 21 CONN. HEADER 1X3, 2.54mm, 3PIN
7	5	J5, J6, J10, J12, J16	Würth Eletronics	613 001 111 21 CONN.HEADER, 1X1, 2.54mm, 1PIN
8	1	J11	Würth Eletronics	691 244 710 004 TERMINAL BLOCK, HORIZONT 4POS
9	2	J19(SMA1), J20(SMA2)	Amphenol RF	132357-11 CONN. SMA RCPT, 50 Ohm NOT STUFF
10	1	R1	Panasonic	ERJ-3EKF4700V RES SMD, 470 Ohm, 1%, 1/10W, 0603
11	3	R2, R3, R4	Panasonic	ERJ-3GEY0R00V RERS JUMPER, 0 Ohm, SMD,1/10W, 0603
12	1	R5	Panasonic	ERJ-3EKF1002V RES SMD, 10K Ohm, 1%, 1/10W, 0603 NOT STUFF
13	6	R7, R8, R9, R10, R12, R13	Panasonic	ERJ-3EKF49R9V RES SMD, 49.9 Ohm, 1%, 1/10W, 0603
14	1	R14	Panasonic	ERJ-H3EF1200V RES SMD, 120 Ohm, 1%, 1/8W, 0603 NOT STUFF
15	2	R6, R11	Panasonic	ERJ-3GEY0R00V RERS JUMPER, 0 Ohm, SMD,1/10W, 0603 NOT STUFF
16	1	U2	MaxLinear	MXL83211/MXL83212/MXL83214

EVK Setup and Configurations

The following table lists the header pin descriptions.

Table 3: EVK Header Pin Description

J1	J1-Pin 1	J1-Pin 2	J1-Pin 3	J1-Pin 4
	GND	NC	V _{CC} ¹	V _{CC} ¹

1. V_{CC} = 3.0V to 5.5V.

The following table lists the header pin factory settings and descriptions. For a complete view of the MxL8321x EVK, see [Figure 1](#) on page 1.

Table 4: EVK Header Pin Description and Default Settings



Header	Factory Setting	Description
	Jumper 1-2	Enables power LED.
	Header 3 pins	■ J3.1: GND. ■ J3.2: Receiver output (RO). ■ J3.3: V_{CC}.
	Header 2 pins	■ J4.1: RO (test point). ■ J4.2: GND.
	Jumper 1-2	Enables receiver, REb = GND.
	Header 2 pins	■ J8.1: REb (test point). ■ J8.2: GND.

Table 4: EVK Header Pin Description and Default Settings (Continued)




Header	Factory Setting	Description
J13 	Jumper 2-3	Enables driver, $DE = V_{CC}$.
J15 	Header 2 pins	■ J15.1: DE (test point). ■ J15.2: GND.
J17 	Header 3 pins	■ J17.1: GND. ■ J17.2: Driver input (DI). ■ J17.3: V_{CC}.
J18 	Header 2 pins	■ J18.1: DI (test point). ■ J18.2: GND.
J9 	Header 2 pins	■ J9.1: B inverting input (test point). ■ J9.2: GND.
J14 	Header 2 pins	■ J14.1: A non-inverting input (test point). ■ J14.2: GND.
J11 	4-pin terminal block	■ J11.1: GND. ■ J11.2: B inverting input. ■ J11.3: A non-inverting input. ■ J11.4: GND.

Table 4: EVK Header Pin Description and Default Settings (Continued)

Header	Factory Setting	Description
J10 	Header 1 pin	J10.1: B inverting input (test point).
J12 	Header 1 pin	J12.1: A non-inverting input (test point).
J6 	Header 1 pin	J6.1: GND.
J5 	Header 1 pin	J5.1: GND.
J16 	Header 1 pin	J16.1: GND.

Layout Recommendations

The following are recommended layout practices that are already applied in the EVK:

- Application of bypass capacitors of at least 100nF as close as possible to the V_{CC} terminal of the device.
Note: If the supply source is generated from a linear power supply or regulator, MaxLinear recommends that you use additional 10 μ F (C2) and 100nF (C3) ceramic capacitors.
- Use of at least two vias for the V_{CC} and ground connections of the bypass capacitors to minimize effective via inductance.
- When possible, use of a V_{CC} and ground plane to provide low-inductance traces and signal path.

For more information and tips on layout, refer to the *RS-232 and RS-485 PCB Layout Application Note* (293AN).



MaxLinear, Inc.
5966 La Place Court, Suite 100
Carlsbad, CA 92008
Tel.: +1 (760) 692-0711
Fax: +1 (760) 444-8598
www.maxlinear.com

The content of this document is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by MaxLinear, Inc. MaxLinear, Inc. assumes no responsibility or liability for any errors or inaccuracies that may appear in the informational content contained in this document. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced into, stored in, or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of MaxLinear, Inc.

EXCEPT AS OTHERWISE PROVIDED EXPRESSLY IN WRITING BY MAXLINEAR, AND TO THE MAXIMUM EXTENT PERMITTED BY LAW: (A) THE MAXLINEAR PRODUCTS ARE PROVIDED ON AN "AS IS" BASIS WITHOUT REPRESENTATIONS OR WARRANTIES OF ANY KIND, INCLUDING WITHOUT LIMITATION ANY IMPLIED OR STATUTORY WARRANTIES AND ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR TITLE; AND (B) MAXLINEAR DOES NOT GUARANTEE THAT THE PRODUCTS WILL BE FREE OF ERRORS OR DEFECTS. MAXLINEAR PRODUCTS SHOULD NOT BE USED IN ANY EMERGENCY, SECURITY, MILITARY, LIFE-SAVING, OR OTHER CRITICAL USE CASE WHERE A FAILURE OR MALFUNCTION COULD CAUSE PERSONAL INJURY OR DEATH, OR DAMAGE TO OR LOSS OF PROPERTY. USERS ASSUME ALL RISK FOR USING THE MAXLINEAR PRODUCTS IN SUCH USE CASE. CUSTOMERS AND USERS ARE SOLELY RESPONSIBLE FOR USING THEIR OWN SKILL AND JUDGMENT TO DETERMINE WHETHER MAXLINEAR PRODUCTS ARE SUITABLE FOR THE INTENDED USE CASE.

MaxLinear, Inc. may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from MaxLinear, Inc., the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

MaxLinear, the MaxLinear logo, and any other MaxLinear trademarks (including but not limited to MxL, Full-Spectrum Capture, FSC, AirPHY, Puma, AnyWAN, VectorBoost, MXL WARE, and Panther) are all property of MaxLinear, Inc. or one of MaxLinear's subsidiaries in the U.S.A. and other countries. All rights reserved.

All third-party marks and logos are trademarks[™] or registered[®] trademarks of their respective holders/owners. Use of such marks does not imply any affiliation with, sponsorship or endorsement by the owners/holders of such trademarks. All references by MaxLinear to third party trademarks are intended to constitute nominative fair use under applicable trademark laws.

The URLs provided are for informational purposes only; they do not constitute an endorsement or an approval by MaxLinear of any of the products or services of the corporation or organization or individual. MaxLinear bears no responsibility for the accuracy, legality or content of the external site or for that of subsequent links. Contact the external site for answers to questions regarding its content.

© 2024 MaxLinear, Inc. All rights reserved.